



STANDARD 4'-0" TOEPLATE:

1. ATTACH TOEPLATE BRACKETS #49F-8 TO END POST FLANGE. USE FLANGE MOUNTING ANCHOR, SUPPLIED BY OTHERS. HAND TIGHTEN ONLY.
2. INSERT 1/4"-20 x 3/4" LG. CARRAGE BOLTS INTO SLOT ON TOEPLATE. INSERT THRU HOLES IN BRACKETS.
3. ATTACH WITH 1/4"-20 LOCKNUT. HAND TIGHTEN ONLY.
4. POSITION ASSEMBLY ON POST, 1/4" GAP MAXIMUM, FROM TOEPLATE TO WALKING SURFACE.
5. TIGHTEN ALL HARDWARE.

THIS DRAWING AND ALL THE INFORMATION THEREON IS THE PROPERTY OF THE HOLLANDER MFG. CO., IS CONFIDENTIAL AND MUST NOT BE MADE PUBLIC, NOR COPIED, NOR USED, TO THE DISADVANTAGE OF SAID HOLLANDER MFG. CO. AND IS SUBJECT TO RETURN ON DEMAND.
 COPYRIGHT 2013.
 HOLLANDER - MANUFACTURING CO.

NO.	REVISIONS	DATE	APPROVED
0	RELEASED FOR APPROVAL	1-15-13	BW

Hollander[®]
 STRUCTURAL ENGINEERING GROUP
 10285 WAYNE AVENUE
 CINCINNATI, OH 45215-6399
 PHONE: (800) 772-8800 FAX: (502) 772-8806
 WWW.HOLLANDER.COM

PROJECT	CUSTOMER	DESCRIPTION
STRAIGHT RAIL TOEPLATE 8'-0" c/c POST 42" HIGH RAIL		MODULAR RAIL SECTION DRAWINGS

DRW NO.	APP'D BY	DATE
92382	BW	1-15-12

PROJ. NO.	REV. NO.	REV. DATE
7069-S	1	

